How to open the TOP of the BOX: The top tab on the long side of the box is tucked into 2 L-shaped notches. Push DOWN on the tab to slide it out of the notches.

INCORRECT. Do NOT pull UP on the tabs. This causes the boxes to rip which means we must buy new ones making our costs (and our prices) go up!

Use the same technique (pushing downward on tabs) to slide the tabs out of the notches. To open the BOTTOM of the BOX: There are two tabs on the shorter sides that are tucked into the notches.

Alternately, you can use your thumbs to push downward and release both sides at the same time.

